



NOTES

1. ALL D.I. JOINTS TO BE RESTRAINED WITH MEGALUG TYPE DEVICES OR APPROVED EQUAL.
2. PROTECTO 401 SHALL BE USED IN ALL D.I. PIPES.
3. SECURE THE DROP PIPE TO THE MANHOLE SIDEWALL WITH $\frac{1}{2}$ " STRAP & BOLTS AROUND EACH JOINT AND MIDWAY BETWEEN EACH JOINT.
4. CHANNELIZE THE MANHOLE TO DIRECT THE DISCHARGE FROM THE DROP IN THE DIRECTION OF THE MAIN FLOW CHANNEL.