



#### NOTES:

1. MATERIALS:
  - 1.1. FOR ASBESTOS CEMENT PIPE USE SS TAPPING TEE WITH FULL CIRCLE SEAL.
  - 1.2. FOR STEEL, DI, AND CI PIPE USE STEEL TAPPING TEE.
2. TAPS TO BE INSTALLED AT CENTER OF PIPE, NOT OFFSET.
3. MIN. 18" DISTANCE BETWEEN TAPS ALONG PIPE.
4. STEEL TAPPING TEES SHALL BE EPOXY COATED.
5. ALL TEES AND VALVES TO BE PRESSURE TESTED BEFORE TAP UNLESS MANUFACTURER DOCUMENTATION IS PROVIDED CERTIFYING THAT TESTING HAS ALREADY BEEN COMPLETED.