


### POLE ORIENTATION & ATTACHMENT POINT DETAIL

PLAN VIEW  
SCALE: N.T.S.



### PEDESTAL FOUNDATION

SCALE: N.T.S.

#### NOTES:

1. SEE STD. TR-SIGN-4 FOR FLASHING BEACON DETAILS.